

RULES OF STOCK ANTIQUE TRACTOR PULLERS 1957 AND OLDER

Class	Tire size
3250	11.2x38-12.4x28
3500	12.4x38-13.6x28
4500	13.6x38-14.9x28
5500	15.5x38-16.9x30
6500	16.9x38-18.4x30
7500	18.4
8500	18.4
UNLIMITED	

1. Drivers must be 18 years of age or older. Drivers 14 to 18 must have a written consent of parents for each pull.
2. Obvious or excessive consumption of alcoholic beverages will be grounds for disqualification.
3. Foul or abusive language will be grounds for disqualification.
4. Drivers must be seated, with one hand on steering wheel at all times.
5. Tractors must be operated in a safe manner at all times. Speed not to exceed 4 mph on or off the track.
6. All tractors must be original in appearance.
7. Any tractor in question of age must have a serial number in the proper place or casting stamp that can be easily read.
8. Tractors must be of two wheel type.
9. All fans, PTO's or exposed moving parts must be shielded.
10. No essential equipment can be removed. Standard tread tractors require fenders. Fenders are optional on row crop tractors.
11. New stock tractors with creeper gear may pull in next higher gear. All others must pull in low gear. No shifting up or down allowed during a pull.
12. Any fuel mixture will be grounds for disqualification.
13. Tractors must be weighed with driver on. If tractor is entered in more than one class, it must be weighed in each class.
14. Any engine speed 5% over standard RPM's will be grounds for disqualification. RPM's will be checked at full throttle by judge using corporation charts for RPM's according to tractor make.

(rules 15 thru 30 on back)

15. Tractor weight may be protested. Both protesters a protested will be reweighed. Judges have the right to reweigh any tractor without protest.
16. Tractors my pull in more than one class, but only once per class.
17. Weights and parts must be securely fastened to tractor. If anything falls off tractor, it will be disqualified from the class.
18. Anytime any part of tractor or skid goes outside boundaries it will be disqualified.
19. Tractors must be natural aspired. No fuel injection or gas under pressure unless factory equipped.
20. If the track judge stops a puller for any reason, the puller will take the distance where he/she is stopped. If stopped within the first 20 feet you will be entitled to one restart. No weight changes allowed.
21. Tractors shall be stopped if the front end raises to high, or higher than the judge thinks is safe.
22. Tractors are allowed factory rated horsepower or factory overhaul replacement horsepower. Judges have the right to check any tractor.
23. Tires must be unaltered factory tread. No cut tires allowed. Rim diameter can't be any larger than original equipment.
24. Tractors must pull from an unaltered factory drawbar not to exceed 18 inches in height or no closer than 18 inches of back axle to center of hitching point.
25. Tractors will pull from a 3" clevis fasten by minimum of 3/4 inch hitch pin or fixed pulling eye of 3 inches. Each puller responsible for his or her own clevis. Maximum drawbar height is 18 inches. No closer than 18inches to axle.
26. Front weights not to exceed 24 inches of front axle.
27. No tractor that normally pulls with modified antiques will be allowed to pull with stock antiques.
28. Standard tractor pulling 8500 and over may have supports on drawbar.
29. Industrial tractor may pull in unlimited class only.
30. The track judges will have the final decision on all rules and regulations of the pull.